Dyno ECU_01 communication protocol

Channels received by AIM loggers connected to Dyno ECU_01 ECU are:

ID	CHANNEL NAME	FUNCTION
ECU_1	DYNO_RPM	RPM
ECU_2	DYNO_SPEED	Speed
ECU_3	DYNO_IAT	Intake air temperature
ECU_4	DYNO_POWER	Power
ECU_5	DYNO_TRACT_EFF	Tractive effort
ECU_6	DYNO_VACUUM	Vacuum sensor
ECU_7	DYNO_LAMBDA	Lambda value