Trijekt Plus V510communication protocol

Channels received by AIM loggers connected to Trijekt Plus V510 ECU are:

ID	CHANNEL NAME	FUNCTION
ECU_1	TRI_RPM	RPM
ECU_2	TRI_RESERVED1	Reserved channel 1
ECU_3	TRI_RESERVED2	Reserved channel 2
ECU_4	TRI_RESERVED3	Reserved channel 3
ECU_5	TRI_WATERTEMP	Engine cooling temperature
ECU_6	TRI_RESERVED4	Reserved channel 4
ECU_7	TRI_BATTVOLT	Battery supply
ECU_8	TRI_TPS	Throttle position sensor
ECU_9	TRI_MAP	Manifold air pressure
ECU_10	TRI_AIRTEMP	Intake air temperature
ECU_11	TRI_EXHAUST_TEMP	Exhaust temperature
ECU_12	TRI_LAMBDA	Lambda value
ECU_13	TRI_FUELTEMP	Fuel temperature
ECU_14	TRI_RESERVED5	Reserved 5 channel
ECU_15	TRI_ERRORS	Errors