



AiM Infotech

Porsche 997 GT3 RSR ECU

Release 1.03



ECU

1 Supported models and years

This tutorial explains how to connect Porsche 997 race cars to AiM devices. Supported models and years are:


- Porsche 997 GT3 RSR from 2007 onwards

2 Wiring connection

These cars are equipped with a Bosch MS4 ECU that features a bus communication protocol based on CAN. This can be reached in two ways:

- using a 5 pins Deutsch female connector placed near the ECU; this connector is mounted as stock on the car harness and is very easy to reach;
- going to the ECU.

Here below you see 5 pins Deutsch female connector pinout on top and connection table on bottom.




5 pins connector pin

Pin function

AiM cable

4	CAN High	CAN+
5	CAN Low	CAN-

Here below you see ECU pinout on top and connection table on bottom.



Bosch MS4 pin	Pin function	AiM cable
60	CAN High	CAN+
58	CAN Low	CAN-

3

AiM device configuration

Before connecting the ECU to AiM device set this up using AiM Race Studio software. The parameters to select in the device configuration are:

- ECU manufacturer "Porsche"
- ECU Model "MS4_997_GT3_RSR"

4

Available channels

Channels received by AiM devices connected to "Porsche" "MS4_997_GT3_RSR" protocol are:

ID	CHANNEL NAME	FUNCTION
ECU_1	GT3_RPM	RPM
ECU_2	GT3_TPS	Throttle position sensor
ECU_3	GT3_OIL_PRESS	Oil pressure
ECU_4	GT3_FUEL_PRESS	Fuel pressure
ECU_5	GT3_FUEL_TEMP	Fuel temperature
ECU_6	GT3_OILT	Oil temperature
ECU_7	GT3_ECT	Engine coolant temperature
ECU_8	GT3_IAT	Intake air temperature
ECU_9	GT3_BATT_VOLT	Battery supply
ECU_10	GT3_MAP_POS	Selected map
ECU_11	GT3_GEAR	Engaged gear
ECU_13	GT3_BRAKE_SW	Brake switch
ECU_14	GT3_WH_SP_FL	Front left wheel speed
ECU_15	GT3_WH_SP_FR	Front right wheel speed
ECU_16	GT3_WH_SP_RL	Rear left wheel speed
ECU_17	GT3_WH_SP_RR	Rear right wheel speed



ECU_18	GT3_STEER_ANG	Steering angle
ECU_19	GT3_VEH_SPEED	Vehicle speed
ECU_20	GT3_LAMBDA1	Lambda 1 value
ECU_21	GT3_LAMBDA2	Lambda 2 value
ECU_22	GT3_GEAR_POT	Gear potentiometer
ECU_23	GT3_GEAR_SH	Gear shift
ECU_24	GT3_PWAT	Water pressure
ECU_25	GT3_MAP	Manifold air pressure
ECU_26	GT3_PCLUTCH	Clutch pressure
ECU_27	GT3_ACC_X	Horizontal acceleration
ECU_28	GT3_ACC_Y	Vertical acceleration
ECU_29	GT3_ACC_Z	Lateral acceleration