



AiM Infotech

Nissan 370Z

Release 1.04

---



This tutorial explains how to connect Nissan cars to AiM devices.

## 1 Supported model and years

---


Supported model and years are:

- Nissan 370Z from 2009 onwards


## 2 Wiring connection

---

Nissan 370Z features a bus communication protocol based on CAN on the OBDII plug located in the left side of the car cockpit as shown here below.



Connector pinout as well as connection table are shown here.



| OBDII connector pin | Pin function | AiM cable |
|---------------------|--------------|-----------|
| 6                   | CAN High     | CAN+      |
| 14                  | CAN Low      | CAN-      |

### 3

## AiM device configuration

---

Before connecting the ECU to AiM device set this up using AiM Race Studio software. The parameters to select in the device configuration are:

- ECU manufacturer "Nissan"
- ECU Model "370Z";

## 4

# Available channels

---

Channels received by AiM loggers connected to "Nissan" "370Z" protocol are:

| ID     | CHANNEL NAME | FUNCTION                   |
|--------|--------------|----------------------------|
| ECU_1  | Z_RPM        | Engine speed sensor        |
| ECU_2  | Z_VEH_SPEED  | Vehicle speed              |
| ECU_3  | Z_SPEED_FR   | Front right wheel speed    |
| ECU_4  | Z_SPEED_FL   | Front left wheel speed     |
| ECU_5  | Z_SPEED_RL   | Rear left wheel speed      |
| ECU_6  | Z_SPEED_RR   | Rear right wheel speed     |
| ECU_7  | Z_BRAKE_POS  | Brake position             |
| ECU_8  | Z_BRAKE_SW1  | Brake switch 1             |
| ECU_9  | Z_BRAKE_SW2  | Brake switch 2             |
| ECU_10 | Z_ECT        | Engine coolant temperature |
| ECU_11 | Z_LOW_OILP   | Low oil pressure           |
| ECU_12 | Z_PPS        | Pedal position             |
| ECU_13 | Z_TC_OFF     | Traction control OFF       |
| ECU_14 | Z_DIFF_CTRL  | Differential control       |
| ECU_15 | Z_ACC_LAT    | Lateral accelerometer      |
| ECU_16 | Z_ACC_LONG   | Longitudinal acceleration  |
| ECU_17 | Z_STEER_ANG  | Steering angle             |
| ECU_18 | Z_STEER_SPD  | Steering wheel speed       |

**Technical note:** not all data channels outlined in the ECU template are validated for each manufacturer model or variant; some of the outlined channels are model and year specific and therefore may not be applicable.